


Below is a handy Color-Coded Quick Reference for the Data Structure of the DSCSA Bar Code:

DSCSA Bar Code



This appears when the **DSCSA bar code** is scanned to Note Pad for risperidONE 1mg:

0100327241001505213019755265341726053110DJ11102

Below is the breakout of the information:

GTIN Number	Bottle Serial Number	Expiration Date	Batch/Lot Number
(01)	(21)	(17)	(10)
00327241001505	301975526534	260531	DJ11102

***Note:** There is *no* globally adopted order in which the information fields contained in the DSCSA bar code is displayed when scanned. Most drug manufacturers display the fields as GTIN + Serial Number + Expiration Date + Batch/Lot Number. All manufacturers lead with GTIN, but the other information may be in a different order.

Application Identifiers:	Sample Drug Info:
AI for GTIN Number :	(01) 00327241001505 (14 numeric characters)
AI for Serial Number :	(21) 301975526534 (up to 20 alphanumeric characters)
AI for Mfg Expiration Date :	(17) 05/31/2026 (<i>format is YYMMDD</i>)
AI for Mfg Batch/Lot Number :	(10) DJ11102 (up to 20 alphanumeric characters)